

Impacts of Urbanization on Water Resources



Raymond Slade, Jr.
Registered Professional Hydrologist



**Wastewater
leak**



**Austin, 1981, Shoal Creek
near 12th Street**



**Area inundated
by 1981 flood in
Austin**

“The goal of life is living in agreement with nature.”

Zeno (335 BC - 264 BC)

Urbanization can impair the quantity and water quality of surface and groundwater

Major components of urbanization shown in blue below

Effects of the component shown in red

Impacts due to the effects shown in black

Urban Construction

Creation of construction sediment, exposure to construction materials and waste, loss of vegetation

Degradation of water quality and loss of biological life in streams, reservoirs, and aquifers due to sediment and runoff contaminated by construction materials and waste

Degradation of water quality due to loss of vegetation to attenuate contaminants in runoff

Impervious ground cover

Increased storm runoff and decreased infiltration

Increase in flooding damages and frequency

Erosion of channels and banks causing loss of property and additional stream sediment

Decrease in recharge volumes to aquifers

Urban land use

Industry, automobiles, lawn fertilizers and pesticides, pets, parking lot sealants

Degradation of water quality for receiving streams, reservoirs, and ground water

Dense population

Increased water use, sewage, and waste disposal

Decrease in surface water and groundwater availability due to increased water use

Degradation of water quality due to sewage leaks and waste-contaminated runoff

Organization of Presentation

Urban Hydrology 101

Impacts of: Urban Construction

Impervious ground cover

Urban land use

Increased water use

Managing development

Mitigation of urbanization impacts

Organization of Presentation

Urban Hydrology 101

Impacts of: Urban Construction

Impervious ground cover

Urban land use


Increased water use

Managing development

Mitigation of urbanization impacts

Runoff increased by impervious cover


Urbanization increases flood peaks for all floods, causing greater losses of life and property. A US Geological Survey study in the Central Texas area documents that a 2-year flood peak (that with a 50% chance of occurring each year) increases by 99% when a rural basin is fully urbanized. Also, a 100-year flood peak increases by 73% when a basin is fully urbanized.



This conceptual hydrograph shows peaks in an urban basin to be higher than those in a natural basin

Also, urban peaks occur sooner after storms than rural peaks, thus less time is available for remedial actions or evacuation from severe floods.

Effects of urbanization on runoff and recharge



Values shown are for comparative purposes—actual values vary geographically

Organization of Presentation

Urban Hydrology 101

Impacts of: Urban Construction

Impervious ground cover

Urban land use

Increased water use

Managing development

Mitigation of urbanization impacts

Construction site runoff

Environmental Impacts

- **Transports toxic pollutants and nutrients**
- **Turbidity limits sunlight penetration and photosynthesis**
- **Reduces oxygen availability**
- **Clogs fish gills**
- **Fills spawning and breeding grounds**
- **Smothers bottom Communities**
- **Reduces visibility for feeding and upsets food chain**

Urban Construction

Construction typically involves removal of vegetation for work access roads and for building of structures, parking lots, and utility lines. Vegetation attenuates much of the contaminants in overland flow, thus its removal causes water-quality degradation of receiving streams. Also, many tons of loose sediment are created during this process—sediment which washes into receiving streams, reservoirs, and aquifers, often prohibiting the use of such water and causing loss of biological life.

Construction sediment can represent the greatest urban threat to aquatic resources.



Construction Sediment

Many studies Nationwide and in Texas document sediment loads in runoff to increase several orders of magnitude from construction areas that cover even much less than 1 percent of the drainage area for the basin. Degradation of water quality from construction sediment is often severe enough to limit or even prohibit water use and often requires expensive remedial action to correct.



Sediment in Barton Creek flood



Sediment in water sample from Barton Springs

Other Construction pollutants

Typical construction site pollutants include fluids from construction equipment, adhesives, paints, cleaners, masonry, cement, fertilizers, pesticides, and wastes from plumbing, heating, and air conditioning installations. Below is an example of pesticides in runoff from Bee Cave Galleria development in the Barton Creek basin.



Bee Cave Galleria in Barton Creek basin



Pesticide washed into creek from improperly stored bags



Dead fish in receiving stream

6.6.2002

Example of Construction Sediment

**Hamilton Pool, West Travis County,
prior to June 2007**



**Road cut for land development in
Hamilton Creek basin began June, 2007**



Example of Construction Sediment (cont.)

Road cut along Hamilton Creek
after rainfall



Hamilton Pool--first rain after
road cut construction began



Organization of Presentation

Urban Hydrology 101

Impacts of: Urban Construction

Impervious ground cover

Increases in flooding damages and frequency

**Erosion of channels and banks causing loss of property and
additional stream sediment**

Decreases in recharge volumes to aquifers

Urban land use


Increased water use

Managing development

Mitigation of urbanization impacts

Relations between impervious cover and runoff

Runoff data from Austin streamflow gages shows runoff from rural areas to be about .05 or 5% of rainfall while runoff is about 40% or rainfall when impervious ground cover is 50%



Data from
City of Austin

Austin, Texas, 1981 Memorial Day flood: 13 people drowned, \$36 million damages

Urbanization increased this flood peak (deemed as a 100-year flood), but the inundated structures were located within the identified 100-year flood plain. At the time, at least 7,000 families were known to live within 100-year flood plains in Austin—most did not know.



Flooded area superimposed on aerial photo of part of Shoal Creek basin



*Mayor wants city
to tell residents
about flood threat*

By JANET WILSON
American-Statesman Staff

Press release after flood


Mayor Carole McClellan wants more than 7,000 families notified that they live on the city's 100-year flood plain.

Bank Erosion


Urbanization causes increases in the number of bankfull flows. A watershed with 25% impervious surfaces is subjected about once every five years to a peak flow equivalent to the 100-year storm under undeveloped conditions. More frequent floods cause bank erosion as shown in photos of streams in developed basins in the Austin area.



Bank Erosion (cont.)



E. Bouldin Creek



Little Walnut Creek



Tannehill Branch



Walnut Creek

Organization of Presentation

Urban Hydrology 101

Impacts of: Urban Construction

Impervious ground cover

Urban land use creates degradation of runoff quality for receiving streams, reservoirs, and aquifers

Increased water use

Managing development

Mitigation of urbanization impacts

Point sources of urban runoff

Discharges from businesses, industry, mining


Permitted – sewage & industry effluent discharges (liquid or solid)

Non-permitted – leaking storage tanks, spills, dumps



Point Sources (cont)

- **Other sources** – construction activities, waste dumps, cemeteries



Non-Point Sources of urban runoff

- **Urban development** — construction, sewage, autos, parking-lots, pesticides, fertilizers, industry, animals




Examples of non-point source contamination

PAH from Parking lot sealants represent a newly discovered major source of urban contamination. PAH (polycyclic aromatic hydrocarbons), a group member of organic compounds formed during incomplete combustion of organic matter, are in fuels such as gasoline, coal, and fuel oil. As the graph shows, PAH levels in runoff from parking lots (including Austin) have been much greater than levels in used motor oil.



Sealants reapplied every few years. About 600,000 gallons of sealant are applied annually in Austin.

Levels of PAH sampled from parking lots



Another example of non-point source contamination: Leaking sewer line in Tannehill Branch, Austin



Wastewater leak in Barton Creek



Algae blooms
March 2, 2002

Leaking sewer line in Barton Creek immediately upstream from Barton Springs, Austin



Algae blooms
May 14, 2004

Urban Stormwater Hotspots

Definition: A land use or activity that produces higher concentrations of trace metals, hydrocarbons or priority pollutants than normally found in urban runoff.

- Auto recycling
- Commercial parking lots
- Fleet storage areas
- Industrial rooftops
- Landscaping/nursery
- Industrial (outdoor storage or unloading)
- Public work areas
- Vehicle service & maintenance
- Vehicle washing/steam cleaning

Urban and Industrial Stormwater: Typical Pollutants



- **Suspended solids/sediments**
- **Nutrients (nitrogen & phosphorus)**
- **Metals (copper, zinc, lead, and cadmium)**
- **Oil & greases (PAHs)**
- **Bacteria**
- **Pesticides & herbicides**
- **Temperature**

Urban Water Quality Degradation



Data from U.S. Geological Survey gages in Austin area

Median water-quality concentrations for rural and urban basins,
for samples collected in Austin during rising stream stages

<u>Water-quality constituent</u>	<u>Median value for rural basins</u>	<u>Median value for urban basins</u>	<u>Percent change in median concentration from rural to urban basin</u>
<u>dissolved solids</u>	245	130	47 % decrease
<u>suspended solids</u>	6.0	410	6700 % increase
<u>biochemical oxygen demand</u>	0.95	6.0	530 % increase
<u>total organic carbon</u>	4.0	18	350 % increase
<u>total nitrogen</u>	0.5	2.15	330 % increase
<u>total phosphorus</u>	0.02	0.45	2150 % increase
<u>fecal coliform</u>	1,000	42,000	4100 % increase
<u>fecal streptococci</u>	1,200	75,000	6150 % increase



**Relation of
impervious
cover (as ratio
of total ground
cover) to mean
values of water
quality
constituents
for gaged
Austin streams**



**Data from
City of Austin**

Organization of Presentation

Urban Hydrology 101

Impacts of: Urban Construction

Impervious ground cover

Urban land use


Increased water use

Managing development

Mitigation of urbanization impacts

Projected total unmet water needs by county, 2050

Data at <http://wiid.twdb.state.tx.us/>




Example of urban well network too dense to provide water during drought

**June 12, 2006
Dry Wells and Existing Wells
Near Northridge Subdivision,
NW Hays County, Texas**

**Groundwater model recommends
28 acre grid well spacing (this size)
to maintain water availability**

**Note: Drought continued
through end of 2006—
additional wells dried up**



AREA OF INTEREST:

Hays County

**Map by
Hays Trinity
Groundwater Conservation District:
12 June, 2006**

Legend:

- ◆ Dry Well (count: 22)
- Probable Existing Well (count in View: 274)

0 0.5 1



Miles

Organization of Presentation

Urban Hydrology 101

Impacts of: Urban Construction

Impervious ground cover

Urban land use

Increased water use

Managing development

Mitigation of urbanization impacts

Urban Water Management Issues

- **Stormwater Management**
- **Nonpoint Sources of Pollution**
- **Source Water Protection**
- **Water Conservation**
- **Wastewater Reuse**
- **Wastewater Infrastructure**

Managing watershed development

Eight tools to protect or restore aquatic resources in a watershed

- **Land Use Planning**
 - **Resource protection**
 - **Watershed based zoning**
- **Land Conservation**
 - **Conservation easements**
 - **Urban watershed forestation**
- **Aquatic Buffers**
- **Better Site Design**
- **Erosion and Sediment Control**
- **Stormwater Best Management Practices**
- **Non-Stormwater Discharges**
- **Watershed Stewardship Programs**

- Center of Watershed Protection

Managing development

Resources

- **The Center for Watershed Protection** presents many strategies for protecting, preserving and restoring watersheds <http://www.cwp.org>
- **The Storm Water Center** is a technical clearinghouse for stormwater practitioners and managers <http://www.stormwatercenter.net>
- **The EPA Stormwater Program**
http://cfpub.epa.gov/npdes/home.cfm?program_id=6
- **The EPA National Menu of Stormwater Best Management Practices**
<http://cfpub.epa.gov/npdes/stormwater/menuofbmps/index.cfm>
- **The International BMP Stormwater Database** features a database of BMP studies, performance analysis results, tools for use in BMP performance studies, monitoring guidance and other study-related publications. <http://www.bmpdatabase.org/>

Click on hyperlinks to access sites

Tools to protect watersheds

- **Vulnerability analyses**
http://www.cwp.org/Vulnerability_Analysis.pdf
- **Watershed assessments**
http://www.cwp.org/st_marys_assessment.htm
- **Retrofit assessment**
http://www.cwp.org/retrofit_article.htm
- **Watershed restoration**
http://www.cwp.org/tools_restoration.htm
- **Rapid stream assessment technique**
http://www.stormwatercenter.net/monitoring%20and%20assessment/r_sat/smrc%20rsat.pdf
- **Conservation assessment**

Organization of Presentation

Urban Hydrology 101

Impacts of: Urban Construction

Impervious ground cover

Urban land use

Increased water use

Managing development

Mitigation of urbanization impacts

Location of development within watersheds

Best Management Practices

Mitigation of impacts of urbanization

The two major topics below involve several tools to protect aquatic resources

- **Location of development within watersheds**

 - Land Use Planning

 - Land Conservation

 - Aquatic Buffers

 - Better Site Design

- **Best Management Practices**

 - Construction pollution prevention

 - Development pollution prevention


 - Stormwater treatment

Location of development within watersheds

The location of development within a basin can be more important in mitigating flooding and water quality degradation than the amount of development.

- Only about 10% of rainfall from a natural basin becomes runoff
 - The remaining 90% of rain is captured by the soil and vegetation in overland flow before entering streams.
 - Soils and vegetation also attenuate water-quality contaminants in overland flow.
 - Development can increase runoff volume and degrade water quality by several hundred percent
 - Contaminated runoff from developed areas adjacent to stream channels receives minimal attenuation by soils and vegetation before entering receiving streams.
- * The amount of urban contaminants entering streams and aquifers can be minimized by:
1. locating developed areas remote from receiving streams and/or the use of buffer zones,
 2. increased vegetation to attenuate contaminants
 3. flat slopes between development and stream--flat land create slower velocities of overland flow, thus providing great time for attenuation of contaminants

Examples of variations in vegetation, slope, and buffer zones



flat slope

buffer zone

thin vegetation

steep slope

dense vegetation

no buffer

Lake Austin

Erosion and Soil Control Practices

<http://www.stormwatercenter.net/Slideshows/ESC.htm>

**Note: Many of these practices
are not used in Texas**

1. Minimize Clearing

2.a. Protect Waterways

Buffers and special crossings for waterways

2.b. Stabilize Drainageways

Checkdams, sod, erosion control blankets, rip rap

3. Phase Construction

4. Rapid Soil Stabilization

hydroseed, mulch, erosion control blankets

5. Protect Steep Slopes

6. Perimeter Controls

Earth dikes, diversions, silt fences, stabilize construction entrance

7. Employ Advance Settling Devices

sediment traps & sediment basins


8. Certified Contractors Implement Plan

9. Adjust Plan as Field Conditions change

10. Assess and Revise Practices After Storms

Repair damage, modify practices, reinforce, cleanout

Effect of erosion and sediment controls on suspended sediment concentrations



Construction site condition



Data from Piedmont, Ca.
(Schueler and Lugbill, 1990)

Construction controls most used in Texas

Silt fences which often fail during large storms



Additional sediment construction controls




Additional sediment construction controls (cont.)


Sedimentation basin with standpipe



Checkdams



Berm dividing multi-cell sedimentation basin



Best Management Practices

Can attenuate flood peaks and/or reduce water quality degradation

Pollution prevention

Municipal - pest control, road and bridge maintenance, illegal dumping controls, parking lot and street cleaning, wastewater system controls

Residential - animal waste collection, landscaping and lawn care, car washing, pest control, automobile maintenance, rain barrels, septic system controls, green rooftops

Stormwater treatment

Ponds - wet, dry extended detention, multiple ponds

Wetlands - shallow marsh, submerged gravel, pond/wetland system

Filtering - grass filter strip, sand or organic filter, on-lot treatment, bio-retention

Infiltration - porous pavement, infiltration trench, infiltration basin,

Open channels - dry swell, wet swell, grass channels

Examples of Stormwater Best Management Practices



Flood peak attenuation



Pervious parking lot



Infiltration basin

Wet pond or wetland



Sand filter – Barton Creek Mall



Grass swell



Slideshows with additional information on stormwater management

- **Why watersheds**
http://www.cwp.org/whywatersheds_files/frame.htm
- **Impacts of urbanization**
<http://www.stormwatercenter.net/Slideshows/impacts%20for%20smrc/sld001.htm>
- **Better site design**
<http://www.stormwatercenter.net/Slideshows/bsd%20for%20smrc/sld001.htm>
- **Eight tools for watershed protection**
<http://www.stormwatercenter.net/Slideshows/8tools%20for%20smrc/sld001.htm>
- **Stormwater Best Management Practices**
<http://www.stormwatercenter.net/Slideshows/smpps%20for%20smrc/sld001.htm>

In closing...

- I would feel more optimistic about a bright future for man if he spent less time proving that he can outwit Nature and more time tasting her sweetness and respecting her seniority.

-- [E. B. White](#)

US author & humorist (1899 - 1985)

Adapt or perish, now as ever, is nature's inexorable imperative.

-- [H. G. Wells](#)

English author, historian, & utopian (1866 - 1946)